# FITTING THE STRAP F G



Attach strap **(F)** to both sides of part **(B)** using the press studs.



Repeat this process with the other strap **(F)** on to both sides of part **(A)**.



Connect main strap **(G)** to straps **(F)** with both clips on either side of the front of the scope.



Repeat this process at the rear of the scope.

Receive the latest Kowa sporting optics news and offers first, visit www.kowasnextbigthing.com and sign up to our newsletter.

Kowa Optronics Co., Ltd. 4th Fl., Toko Bldg, 4-11-1, Nihonbashi-Honcho Chuo-Ku, Tokyo 103-0023 | Japan

T: +81-3-5651-7061 info@kowa-PROMINAR.com www.kowa-PROMINAR.com

### Kowa Optimed Deutschland GmbH

Fichtenstr. 123, 40233 Dusseldorf | Germany

T: +49 (0) 211-542184-00 scope@kowaoptimed.com www.kowaoptic.com

### Kowa American Corporation

20001 South Vermont Avenue, Torrance, CA 90502 | U.S.A.

T: +1 (800) 966-5692 customerservice@kowa.com www.kowa-usa.com



# C-99N STAY-ON-CASE



## FITTING INSTRUCTIONS

# CASE PARTS



## OBJECTIVE LENS CAP STORAGE



The objective lens hood (D) includes a useful objective lens cap holder. This holder is designed to hold the objective lens cap when the scope is in use. (FIG 1) CAUTION: Always remove the objective lens cap from the holder and secure it back on to the scope body when transporting your scope and the objective lens hood is attached to the main body of the case. (FIG 2)





Wrap part (A) around the barrel of the scope.



Slide part **(B)** over the eyepiece and fit it onto the scope body.



Secure with press-studs on both sides.



Secure with the press-studs on the top and bottom of part (A).



Secure on to both sides of part **(B)** using the press studs



Secure part **(A)** using the three press studs on the under side of the scope.



Connect parts (A) and (B) using part (C).



Slide on the objective lens hood (D).



Slide the eyepiece cap **(E)** over the eyepieces.



Secure the stay-on-tab to part **(B)** using the press