FITTING THE STRAP





Slide strap **(F)** over the front of the scope and secure to the press studs on both sides of part **(A)**.



Attach the two front clips on strap **(E)** to the rings on strap **(F)**.



Attach the rear clip on strap (E) to the ring on part (B).



Ensure the strap is not twisted before use for maximum carrying comfort.

Headquaters **Kowa Optronics Co., Ltd.** 2F Kudan Center Bldg. 4-1-7, Kudan-Kita, Chiyoda-Ku,Tokyo, 102-0073 Japan

T: +81-3-5651-7061 E: info@kowa-prominar.com www.prominar.com Europe

Kowa Optimed Deutschland GmbH Fichtenstrasse 123, 40233 Düsseldorf Germany

T: +49 (0) 211-542184-00 E: scope@kowaoptimed.com www.kowaoptic.com US

Kowa American Corporation 20001 South Vermont Avenue Torrance, CA 90502 | U.S.A.

T: +1 (800) 966-5692 E: customerservice@kowa.com www.kowaoptics.com





C-55-N STAY-ON-CASE



FITTING INSTRUCTIONS





Pull part (A) over the barrel of the scope.



Slide part **(B)** over the eyepiece and fit over scope body. The plastic loop should be at the top.



Connect part **(B)** to part **(A)** using the press studs on both sides of the scope.



Slide the eyepiece cap **(D)** over the eyepiece.



Secure on to both sides of part **(B)** using the press studs.



Secure the stay-on-tab to part **(B)** using the press stud.



Slide on the objective lens cap (C) and secure on to the top press stud on part (A).



Secure the stay-on-tab to part (A) using the press stud on the underside of the scope.